

The essential SLIDE-N-SIZE



The new metal expandable Slide-N-Size (ITEM #29505) is really four sizers in one...

Size a balloon any diameter from 1.5" to 18"...

Setup: Insert the folded metal ruler into a foot and line up the holes. Screw in a sizing pole. Slide a second foot onto the ruler, so the left edge lines up with the desired size. Lock it in place with another pole. Want a new size? Just turn the pole, slide the base, and re-lock.

Use: Inflate a balloon with air or helium, then let out gas until it just touches the poles. That's it. You're done.



Size two small balloons at the same time...

Setup: Slide a third foot onto the folded ruler so the distance between the feet is the same. Secure it with the third sizing pole.

Use: Inflate a balloon in each hand, and again let out air until they just touch the poles. With practice, you'll now be twice as fast.



Size two large balloons—even different sizes...

Setup: Unfold the ruler, then setup with the three feet and sizing poles positioned as desired. Do you sell some bouquets of 11" balloons, and others with 16"? No problem.

Use: Size balloons together, or alternate as you prefer, without resetting the sizer.



Wow! Size balloons up to 36"...

Setup: Unfold the ruler and setup with the three feet and two sizing poles as shown. Place the pole extenders over the sizing poles to lengthen them.

Use: As above.



Other uses for the Slide-N-Size:

- Double-stuff balloons quickly on the upright sizing poles.
- Set/confirm auto-sizer timing.
- Use as calipers to measure replacement balloon size in arches and sculptures.



www.Clik-Click.com